

# Safety Alert

## Safety Alert



### Communication of Safety Information

#### The Hazard

Bonded Asbestos Fibro Sheeting in Wet Areas, i.e. kitchens, toilets, bathrooms and laundry.

Houses built prior to 2003 may have asbestos fibro sheeting in wet areas.



#### The Risk

Risk Score: **Very High**

- Possible terminal illness, such as asbestosis or mesothelioma from exposure to asbestos fibres.

#### What needs to be done?

##### Tilers

- **You cannot use power tools** to spot place broken or damaged wall tiles, including skirting tiles in a wet area that has fibro sheeting.
- If there is a possibility (risk assessed) that you might break or damage any fibro sheeting when spot replacing the tiles, you must stop work and contact the Willowdene Supervisor immediately.
- Furthermore, under no circumstances can any power tools be used on Asbestos Containing Material (A/C), i.e. Fibro Sheeting.



PLEASE DIRECT ANY QUERIES REGARDING THIS SAFETY ALERT TO:  
NICK PETROPOULOS PH 0417 684 825